

Portable Oil Condition Test Kit 86000-4

- Rapid go/no-go testing
- Ready to use
- Five simple to use tests
- Rugged fitted case

A portable kit which allows rapid 'go/no-go' checks on in-service oils to evaluate degradation and contamination. Suitable for lubricating oils, crank case, hydraulic, gear, turbine and compressor oils.

Water Content

A digital test cell gives a numeric readout of water content when the sample is mixed with two reagents.

Total Base Number

The same digital test cell will display the TBN when the sample is mixed with another reagent.

Salt Water Contamination

A bottle of reagent and a pack of test pads that change colour in the presence of salt water are provided.

Insoluble Content

A pack of blotter spot test sheets is included, allowing visual determination of insoluble content.

Comparative Viscosity

A Tri-Gauge comparative viscometer allows the viscosity of the sample to be compared to two standards.



Specifications:

Size (HxWxD):	17 x 47 x 36 cm
Weight:	8.1 kg